



FREELANDER 3.2L PETROL

Engine Parts

Description	Vin. Variation	Part Number	Notes
Engine O/Haul Gasket Kit			
VRS Gasket Kit			
Cylinder Head Complete		LR006419	
Cylinder Head Bolts		LR002553	(14)
Exhaust Valves		LR001412	
Inlet Valves		LR001413	
Lifters			
Pistons		LR001977	Class D
Pistons		LR002565	Class C
Pistons		LR002921	Class E
Pistons		LR003616	O/S 0.4
Piston Rings		LR001404	STD
Piston Rings		LR001405	O/S 0.4
Main Bearings			
Big End Bearings		LR003613	STD
Big End Bearings		LR003614	O/S 0.25
Big End Bearings		LR003615	O/S 0.50
Oil Pump	>7H003909	LR005275	
Oil Pump	7H003910>	LR005997	
Valve Stem Seals		LR002556	(24)
Head Gasket	>7H038350	LR002056	
Head Gasket	7H038351>	LR006664	
Inlet Manifold Gasket		LR001454	(6)
Exhaust Manifold Gasket		LR001455	
Rocker Cover Gasket		LR001978	
Front Crank Seal		LR001418	
Rear Crank Seal			
Sump Gasket			
Timing Cover Gasket to Block	>7H038350	LR001447	
Timing Cover Gasket to Block	7H038351>	LR007166	
Timing Cover Gasket Outer		LR001448	
Timing Cover O'Ring		LR002819	
Engine Mount	>7H010766	LR001179	
Engine Mount	7H010767>	LR006278	

Engine Electrical Parts

Description	Vin. Variation	Part Number	Notes
Alternator		LR002426	
Starter Motor		LR002348	

Engine Cooling Parts

Description	Vin. Variation	Part Number	Notes
Radiator	>7H037400	LR002641	
Radiator	7H037401~8H000001	LR006715	
Radiator	8H000002~8H037412	LR002641	
Radiator	8H037413>	LR006715	
Radiator Cap		LR000243	
Top Radiator Hose		LR000931	
Lower Radiator Hose		LR005294	
Water Pump		LR006861	
Water Pump O'ring		LR006072	
Water Pump Gasket			
Viscous Coupling & Fan Assy		LR002660	Heavy Duty Fan
Viscous Coupling & Fan Assy	>7H043352	LR002661	STD
Viscous Coupling & Fan Assy	7H043353~8H000001	LR006992	STD
Viscous Coupling & Fan Assy	8H000002~8H043486	LR002661	STD
Viscous Coupling & Fan Assy	8H043487>	LR006992	STD
Thermostat	>7H002160	LR006071	
Thermostat	7H002161~8H000001	LR003203	
Thermostat	8H000002~8H002156	LR006071	
Thermostat	8H002157>	LR003203	
Thermostat O'ring		LR001517	
Expansion Tank		LR004080	

Fuel Parts

Description	Vin. Variation	Part Number	Notes
Fuel Pump W/Vapour Recovery		LR005619	
Fuel Pump W/O Vapour Recovery		LR005621	
Air Flow Meter		LR002141	

Brake, Suspension and Hub Parts

Description	Vin. Variation	Part Number	Notes
Brake Master Cyl.	>7H040933	LR001050	
Brake Master Cyl.	7H040934>	LR007378	

Front Disc Rotors		LR000470	
Rear Disc Rotors		LR001019	
HUBS			
Front Hub		LR003157	
Rear Hub		LR001127	
Rear Hub Bearing		RFC000010	
Suspension			
O/S/F Shock Absorber		LR001139	
N/S/F Shock Absorber		LR001141	
O/S/R Shock Absorbers		LR005573	
N/S/R Shock Absorbers		LR005574	

Drive Train

Description	Vin. Variation	Part Number	Notes
Front Propeller Shaft	>7H036404	LR001157	
Front Propeller Shaft	7H036405>	LR006959	
Front Diff Pinion Seal		LR003152	
Rear Diff Pinion Seal		LR002883	

Steering Parts

Description	Vin. Variation	Part Number	Notes
Power Steering Pump		LR003776	
N/S/F Tie Rod End		LR002609	
O/S/F Tie Rod End		LR002610	
Steering Damper			

Manual Transmission Parts

Description	Vin. Variation	Part Number	Notes
Clutch Master Cylinder			
Clutch Master Cylinder Kit			
Slave Cylinder			
Slave Cylinder Kit			
Clutch Kit			
Clutch Drive Plate			
Clutch Pressure Plate			
Release Bearing.			